




Guide No. 78086

MOUSE TRAP™

CARTRIDGE INSTRUCTIONS


For use with the Atari® Video Computer System™ and
Sears Video Arcade™.

- For color or black-and-white TV
- Select from four skill levels



COLECO

GAME DESCRIPTION



Here's your home version of the fun-filled Exidy arcade game! MOUSE TRAP™ for Atari® features a cheese-chomping mouse that you dash around a dangerous maze. Open and shut maze doors to escape the pursuing cats. Eat a bone, then turn your mouse into a cat-biting dog for a few moments. Gather points by eating the cheeses that line the paths of the maze. Devour them all and move on to even harder action!

GETTING READY TO PLAY



- Make sure the Video Computer System™ is connected to the TV and the power adapter switch is plugged in.

- **Be sure the B-W/Color switch is set to the "Color" position.**


To play a fun game variation, Invisible Maze MOUSE TRAP™, set the B-W/Color switch to "B-W". This variation features the same game play as MOUSE TRAP™, but the maze, cheeses and bones are invisible.

- Be sure you have plugged a joystick controller into the left jack at the rear of the Video Computer System™.
- Insert cartridge as shown, then turn **On/Off** switch to **ON**.
(ALWAYS TURN THE ON/OFF SWITCH TO OFF WHEN INSERTING OR REMOVING A CARTRIDGE.)

ATARI® Video Computer System™



USING YOUR CONTROLS



NOTE: Use only the left controller for MOUSE TRAP™.

1. **CONTROL STICK:** Push the Control Stick up, down, left or right to make the mouse or dog move in that direction.
2. **RED BUTTON:** Press the Red Button with a quick, sharp tap to change your mouse into a dog. Press the Red Button for a longer period to move the doors.

HERE'S HOW TO PLAY

STEP 1: Choose your skill level.

Set the Difficulty Switches to choose the amount of challenge you want!

Left Difficulty Switch

Smart Cats: A

Dumb Cats: B

Right Difficulty Switch


Fast Cats: A

Slow Cats: B

Then press the Game Reset Button.

STEP 2: The race is on!

After you select your Game Option, the first of your three mice appears in the maze. Move the mouse through the maze and try to eat all the cheeses.



STEP 3: Cat and mouse.

Watch out for the pursuing cats! Open and close maze doors to block their paths. Become an expert at pressing the Red Button for just the right amount of time to foil their chase.

STEP 4: Dog gone it!

Are the cats ganging up on you? Get your revenge! Your mouse can become a cat-biting dog if it has eaten a bone. Check the Bones Remaining Indicator. (Notice that the mouse has already eaten one bone at game start.) If you have a bone, press the Red Button for just the right short period to turn your mouse into a cat-biting dog for a few happy moments. Remember, each time you change your mouse into a dog, you use up one bone. So eat more bones and save them up for emergencies. But be careful. You can save only up to four bones at a time.

The game ends when all your mice have been eliminated.

SCORING




| | |
|--------------------|------------|
| Eating a cheese: | 1 point |
| Biting a cat: | 10 points |
| Clearing the maze: | 100 points |



You get three mice at game start. Each time your score reaches a multiple of 500, you earn a bonus mouse.

THE FUN OF DISCOVERY

This instruction booklet will provide the basic information you need to get started playing MOUSE TRAP™, but it is only the beginning! You'll find that this cartridge is full of special features to make MOUSE TRAP™ exciting every time you play. Experiment with different techniques — and enjoy the game!



90-DAY LIMITED WARRANTY

Coleco warrants to the original consumer purchaser in the United States of any video game cartridge it manufactures, that the cartridge will be free of defects in material or workmanship for 90 days from the date of purchase under normal in-house use.

If your cartridge fails to operate properly DURING THE FIRST 90 DAYS AFTER PURCHASE, return it postage prepaid and insured, with your name, address, proof of the date of purchase and a brief description of the problem, to the Factory Service Station as listed. If your cartridge is found to be factory defective during the first 90 days, it will be repaired or replaced at no cost to you. If the cartridge is found to have been consumer damaged or abused it therefore will not be covered by the warranty, then you will be advised in advance of repair costs.

Coleco's sole and exclusive liability for defects in material and workmanship shall be limited to repair or replacement at its authorized Coleco Service Station, and Coleco shall in no event be liable for incidental, consequential contingent or any other damages, (some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you). This warranty does not obligate Coleco to bear the cost of transportation charges in connection with the repair or replacement of defective parts.

This warranty is invalid if the damage or defect is caused by accident, act of God, consumer abuse, unauthorized alteration or repair, vandalism or misuse.

This warranty is made in lieu of any other express warranty, and except for the foregoing warranty which is exclusive, there is no other express warranty being made.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

CARTRIDGE SERVICE POLICY

If your cartridge requires service after expiration of the 90 day Limited Warranty period, Coleco will service the cartridge and put it in working condition or replace it with a reconditioned unit (at our option), on receipt of your cartridge, postage prepaid and insured, with your check in the amount of \$10.00 payable to Coleco Industries, Inc.

For service information regarding your Coleco cartridge call 1-800-842-1225. This service station is in operation from 8:00 a.m. to 4:30 p.m., Eastern time, Monday thru Friday.

Coleco's service obligation does not apply to defects arising from abuse, misuse or alteration of the cartridge. If the cartridge is found to have been consumer damaged or abused it therefore will not be covered by the warranty, then you will be advised in advance of repair costs.

Please allow 4 to 6 weeks for repair and return.

All returns must be directed to: **Coleco Industries, Inc.**
Consumer Electronics Department
P. O. Box 47
Amsterdam, New York 12010
Attention: Consumer Quality Manager



MOUSE TRAP™ is the trademark of Exidy, Inc.

© 1981 Exidy Incorporated

Atari® and **Video Computer System™** are trademarks of Atari, Inc.

Sears Video Arcade™ is a trademark of Sears Roebuck & Co.

Package, Program and Audiovisual © 1982 Coleco Industries, Inc. Amsterdam, New York 12010

Printed in U.S.A.